



CFE PRODUCTS
JK CUSTOM AM-FM ANTENNA
MODEL #JK-ANT
Jeep Wrangler JK
2007 & UP



- 1 - Remove factory am-fm antenna
- 2 - Install new plastic bezel on top of factory bezel, using antenna adapter stud.
- 3 - Tighten antenna stud just until it becomes snug.
- 4 - Install new antenna.
- 5 - There is also an optional *quick disconnect* shown below.



Questions or Comments ? call CFE PRODUCTS

@ 610 358 1886 / ASK FOR BOB