



CFE PRODUCTS  
TJ CUSTOM AM-FM ANTENNA  
MODEL #TJ-ANT  
Jeep Wrangler TJ  
1997 to 2006



INSTALLATION INSTRUCTIONS

- 1 - Remove factory am-fm antenna.
- 2 - Install new plastic bezel, using antenna adapter stud.
- 3 - Tighten antenna stud just until it becomes snug.
- 4 - Install new antenna.
- 5 - There is also an optional **quick disconnect** shown below.



Questions or Comments ? call CFE PRODUCTS  
@ 610 358 1886 / ASK FOR BOB